

































































































5. After you acknowledge the password (or not), the units are connected and communicating. You can begin using the device.
6. If you need more settings for the unit, tap **Previously connected devices**.
7. Tap  next to the device name.

**Note!** Because the devices are now paired, when you turn on Bluetooth on your device and the other device is on, the connection reestablishes and they'll stay paired until you unpair them.

## Unpair devices




1. From the Home screen, tap  **Set** →  **My other connections** → **The Bluetooth connection**.
2. Tap **Previously connected devices**.
3. Tap  next to the device name that you want to unpair.
4. Tap **Forget**.

**Note!** To disconnect you can turn off the other unit or disable Bluetooth on that device.

## Aeroplane mode

In **Aeroplane mode** you can't make or receive calls, surf the web or download emails, or do anything that requires an Internet connection, this is to prevent disturbance to sensitive equipment. You can still play games, listen to music, watch videos and other content, as long as all this content is saved on your memory card or internal storage.


When you take your phone abroad, you can keep it in flight mode. If you do that, there's no chance of data roaming charges, and you can still enable Wi-Fi. Enable **Aeroplane mode** when in areas with no network coverage to save battery since the phone repeatedly scans for available networks and this consumes power. You can be notified by alarms, if alarms are activated.

1. From the Home screen, tap  **Set** →  **Advanced settings** → **Network & Internet**.
2. Tap  to activate the **Aeroplane mode**.

**Tip:** To enable/disable you can also press and hold the **Power button** and then select **Aeroplane mode** in the menu that opens.

✈️ is shown in the status bar when enabled.

## Connect the phone to a computer



Connect the phone to a computer and start transferring pictures, music and other file types. All you have to do is connect a USB cable between the phone and computer. From your computer's file explorer, you can drag and drop content between your phone and the computer.

**Note!** You might not be able to transfer some copyright-protected material.

**Tip:** If default storage location is set to memory card, all photos and videos taken by the phone are stored in the **DCIM/Camera** folder on the memory card.

## Drag and drop content between phone and a computer

1. Connect your phone to a computer using a USB cable.

**Note!** You might need to wait for the driver to be installed on your computer before you can access the phone.

Mac users, see <https://www.android.com/filetransfer/>.

2. Open the notification panel on the phone by swiping down from the status bar. Tap **Android system/ Tap for more options.** and select **File transfer.**
3. You are prompted, on the computer screen, to choose what to do when you connect your phone to a computer.
4. Select to open the device and view files in the computers file explorer.



5. Wait until the phone/memory card appears as external disks in the computer's file explorer.
6. Drag and drop selected files between the phone and the computer.
7. If necessary, also use the **Safe to remove hardware** function on your computer.
8. When done, remove the USB cable.

**Tip:** You can select different connection modes for your phone when connecting to a computer. Swipe down the status bar and tap to select one of the options.

**Note!** When the phone/memory card is mounted to the computer, the phone cannot access the memory card. Some functionality and applications in the phone, such as the camera, may not be accessible. You can transfer files by using a USB cable on most devices and operating systems supporting a USB Mass Storage interface.

## My phone information

To access device information such as the current software version, battery status or to update device software.

1. From the Home screen, tap  **View** →  **My phone information**.
  - **Battery info** to access information and statistics about battery status and battery usage history.
  - **Storage** check the status of the used and available memory.
  - **Phone status** to check system and software versions and more.
  - **Device update** to check for available software updates.

## Updating your device

When your device is connected to a Wi-Fi network it's directly updated to the latest software by the firmware over-the-air (FOTA) service.

**Note!** During an update your phone will be temporarily out of service, even for emergency calls. All contacts, photos, settings, etc. will remain safely stored in the phone. Do not interrupt the update process.




**IMPORTANT!**


We recommend that you always update your device to the latest software version to get optimal performance and the latest enhancements. When a new software is available, a notification message is shown in the status bar, or as a notification. Select it to start downloading. The download time may vary depending on Internet connection.

## Backup

Your Google account information is set to back up automatically. Follow below settings to make sure your contacts, system settings, apps, calendar, and email will be restored whenever you set up a new device with that same Google account.

### Backup with Google

1. From the Home screen, tap  **Set** →  **Advanced settings** → **System**.
2. Scroll to and select **Backup** and make sure that the switch is ON  to keep device data safe.

There are many apps that allow you to backup your photos, applications and much more. Some apps even offer cloud storage that allows mobile uploading, and others that allow you to restore your data should you need to. Try searching  **Play Store**, see *Google™ Play Store*, p.43

## Reboot the phone

The reason to perform a reboot might be a persistent problem that is impossible to solve or if your device becomes frozen and unresponsive. This device has an internal battery and therefore the hardware cannot be rebooted by removal of the battery.

- Should you need to reboot the phone, press and hold the **Power button** and the **Volume down key** simultaneously for more than 8 seconds or until you feel a vibration to reboot it. After the reboot, the phone will restart automatically.

## Reset the phone

### IMPORTANT!

Resetting the phone means that most information, such as downloaded and installed applications, accounts, system and application data and settings, will be erased. Be sure to backup any data and files you want to keep before you perform the reset. A backup is a safety copy of information. Carefully read all the text below before you start.

The reason to perform a reset might be a persistent problem that is impossible to solve or if you want to pass the phone to someone else.

**Note!** Everything added to the phone since you got it will be erased!



### Exceptions

- Everything saved on an **SD card** if you have one installed (see *Insert SIM card and memory card*, p.3 and *External memory*, p.40).
- Applications and data by Google™ — if backup is enabled, see *Backup*, p.38.
- Information you have stored in any cloud storages (or on a computer, see *Connect the phone to a computer*, p.36).

### IMPORTANT!

Remember the Google account your phone last logged in to. During a reset Google's anti-theft mechanism requires you to enter the Google account your phone last logged in to on the startup navigation screen for identity authentication. Your phone can properly power on only after the identity authentication passes.

## Reset the phone

1. From the Home screen, tap  **Set** →  **Advanced settings** → **System** → **Advanced** → **Reset options**:
2. **Reset Wi-Fi, mobile & Bluetooth** to reset all network settings, including Wi-Fi, Mobile data, Bluetooth.. Carefully read the on-screen information, it is **important!**
3. **Reset app preferences** to reset app preferences for:
  - Disabled apps.
  - Disabled app notifications.
  - Default applications for actions.

- Background data restrictions for apps.
- Any permission restrictions.

You will not lose any app data or the app itself, only any changed settings for the app.

4. **Erase all data (factory reset)** to erase all data from your phone's **internal storage**, including:
  - Your Google account.
  - System and app data and settings.
  - Downloaded apps.
  - Music/videos/photos.
  - Other user data.



### CAUTION

This is the last step before ALL data from the device, including Google or other account settings, system and application data and settings will be **permanently** erased.

5. After your phone resets, it will be set back to factory defaults and will be just like it was when it came out of the box.

## Memory and storage

**Note!** When you update the phone the available capacity may change.

Your phone has different types of memory and storage possibilities.

### Internal storage

The internal storage is used to store downloaded or transferred content along with your personal settings and data. Examples are alarm, volume and language settings, emails, bookmarks, contacts, calendar events, photos, videos and music.

### External memory

You can use an external memory card to get more storage space or as a portable memory. There are many different media card standards, use only compatible memory cards. Compatible card type for this device: microSD, microSDHC, microSDXC max 128 GB. SD stands for Secure Digital. Lower-capacity cards store less information. The phone works with or without an SD card installed. We suggest you to use a high speed memory card, especially

if used as extended internal memory. Most applications can read data from a memory card but only certain apps can save files to this type of memory. You can, for example, set the camera application to save photos directly to the memory card.



**Note!** If you insert an external memory, it is recommended you change the default storage location. This allows you to save more files on your phone, like pictures and videos. We recommend that you regularly copy your photos from the phone's internal storage to your computer as a form of backup, see *Connect the phone to a computer*, p.36. These files are found in the DCIM folder on your phone. DCIM stands for Digital Camera IMages and it is the default directory structure for digital cameras and for smartphone cameras.

## Free up memory space

The memory in your device tends to fill up as a result of normal usage. If your phone starts to slow down, or applications suddenly shut down, consider the following:

### Free up space

When you are surfing the web or using apps on your phone, that will create temporary files stored on your phone in an area of memory called cache. The reason is that the next time you visit the same website or app the phone will load it from cache memory instead of downloading everything again from the server which, take up time and bandwidth. These files will overtime become obsolete and will then be called **Junk files**. Follow below to delete **Junk files** and other files.

1. From the Home screen, tap  **View** →  **My phone information** → **Storage**.
2. Tap **Internal shared storage** to see the different types of data on your internal memory.
3. Tap **Free up space** to delete **Junk files** which are obsolete system and app files. .



**Tip:** The **Junk files** will increase again over time, and you'll want to perform again.



## Delete pictures

- If you use your phone to take a lot of pictures, remember to back them up on your computer every now and again. Not only will this prevent you from losing any photos if anything were to happen to your phone, but it also gives you the opportunity to delete them from your phone and free up space. You can access your pictures by simply plugging your phone into your computer via a USB cable, see *Connect the phone to a computer*, p.36.
- There are also several services to use if you want to back up your photos – in many cases, automatically. Preloaded to this phone is the Google application, **Photos**, that supports unlimited storage, photo and video back up, and even create mini-albums for you.



## Uninstall applications that you don't use

1. From the Home screen, tap  **View** →  **My applications**.
2. Find the application you don't use anymore and press and hold the icon.
3. Tap **Uninstall**.
4. Tap **OK** to confirm.



**Note!** Some applications are pre-installed and cannot be uninstalled.



All purchases are managed by your Google account. If you want to install a particular app again later on, as long as you are signed in with your original Google account you won't be charged again for the same app.

## Change the SIM PIN code

1. From the Home screen, tap  **Set** →  **Advanced settings** → **Security & location** → **Advanced** → **SIM card lock**.
2. Tap **Change SIM PIN**.
3. Enter old PIN and tap **OK**.
4. Enter new PIN and tap **OK**. Enter new PIN again and select **OK** once more. When done, **SIM PIN changed successfully** will appear.

## Activate/deactivate SIM card lock

1. From the Home screen, tap  **Set** →  **Advanced settings** → **Security & location** → **Advanced** → **SIM card lock**.
2. At **Lock SIM card**:

- Switch  to activate PIN code. You need to enter the PIN code every time the phone is started.
- Switch  to deactivate PIN code.

**WARNING**

If the SIM card is lost/stolen it is unprotected.

## Google™ Play Store

### IMPORTANT!


You need an Internet connection to use this service. It is recommended to use Wi-Fi connections when available to reduce costs for data traffic. Contact your service provider for detailed subscription costs.



**Note!** You need to have a Google™ account to use **Play Store**. Your Gmail account is also your Google Account, so you can use the same Gmail username and password to use other Google products like YouTube, Google Play, and Google Drive.

Browse the available applications and games through different categories or through the lists like Top paid and Top Free. You can also search for a specific application or game.



Some applications need to be purchased. The cost is shown in the application description, the same goes if the application is free. You pay using Google™ Pay, which can be registered when setting up a Google™ account or the first time for a purchase.

### Install applications




1. From the Home screen, tap  **Play Store**.
2. Find an item you wish to download by browsing categories or by using the search function.
3. Tap the item to view its details, and follow the instructions to complete the installation/purchase.

**Tip:** All downloaded applications can be found in  **Play Store**. Tap , and tap to select **My apps & games**.

## Open an installed application




1. In  **Play Store**, tap  and tap to select **My apps & games**.
2. Select the downloaded application. If needed tap **Open**.

## Update an installed application

1. In  **Play Store**, tap  and tap to select **My apps & games**.
2. You can select to update all applications that needs to be updated, tap **Update all**, or select a specific application and tap  **Update** and confirm.

**Note!** You will get a notification whenever there's an update for any of your installed apps. Please always update to the latest version for best performance and security of the app.


## Uninstall applications




1. In  **Play Store**, tap  and tap to select **My apps & games**.
2. Tap to select an application, tap  **Uninstall** and confirm.

**Tip:** You can also press and hold an app icon and then tap **Uninstall**.

## Calls

### Make a call


To call a contact that is currently not available in your contact book, see also  *Call*, p.25.

1. From the Home screen, tap  **Call**.
2. Tap  **A number**.
3. Enter the phone number, you are offered suggestions as you type.
4. Tap  to call or tap directly on the suggested contact.



**Tip:** For international calls, use the international prefix + before the country code. Touch and hold **0** until + is shown.

### Answer a call



The phone rings or vibrates to alert you to an incoming call.

**Note!** The phone will not ring if the phone is set to **Vibration mode** or ring/vibrate if the phone is set to **Silent mode**. The phone will not ring, vibrate or even turn on the screen if you have set it to **Do not disturb mode**, see more in *Sound settings* , p.32.

The sound you hear when the phone rings is known as the *ringtone*, see *Ringtone and other tones*, p.32. You can set your phone to play a number of ringtones, for example depending on who's calling, or you can set a universal ringtone.

1. Tap  to enable **Silent mode**.
2. Tap  to enable **Vibrate mode**.
3. The touchscreen display lights up, giving you more information about the call.
4. You now have some options.

#### From locked screen

- **Answer the call** swipe up .
- **Reject the call** swipe down .
- **Silence the ringer** press the volume button (up or down) to silence the ringer.

#### From unlocked screen

- **Answer the call** tap **Answer**
- **Reject the call** tap **Reject**
- **Silence the ringer** press the volume button (up or down) to silence the ringer

## End a call

- Tap  to end.

## Options during a call

### Volume control



- Use the side volume keys to adjust the call volume, the selected level is shown on-screen.

### Mute



1. During a voice call, tap .

2. To disable, tap once again.

### Keypad (tone sending)

1. During a voice call, tap .
2. Enter number.
3. To close the keypad, tap .

### Loudspeaker

1. During a voice call, tap .
2. Speak clearly into the microphone at a maximum distance of 1 m. Use the volume keys to adjust the loudspeaker volume.
3. To disable, tap  once again.

**Note!** During a voice call more actions can be available, depending on the region, service provider, model specifications, or software.

## Headset

### Headset







- Connect a headset to the headset socket. The internal microphone in the phone is automatically disconnected.






### CAUTION

Using a headset at high volume may damage your hearing. Adjust the volume level carefully when using a headset.

## Call log

1. From the Home screen, select  **View** → **My call history** .
2. Tap a number or a contact to:
  - To call, tap .
  - Press and hold a number/contact for more options tap  To call, tap .
  - For more general call log options tap .




### Clear the call log

1. From the Home screen, select  **View** →  **My call history**.
2. Tap  and select **Call history**.

3. Tap  → **Clear call history** to clear all.

## Call settings




Lock the screen during calls, call log limitation and more

1. From the Home screen, tap  **View** →  **My call history** → .
2. Tap **Settings** to view the call settings.

**Tip:** For more help about call settings, see [support.google.com/phoneapp/](https://support.google.com/phoneapp/)

## SOS calls

As long as the phone is switched on, you can always make an SOS call.



1. From the Home screen, tap  **Call**.
2. Tap  **A number** to enter the main local emergency number for your present location.
3. Tap .


Some networks accept calls to emergency numbers without a valid SIM card. Contact your service provider for more information.

# Contacts

## Add new contact



Your contacts are automatically synced with your Google account (provided that you are logged onto your Google account). To manage synchronisation for your Google account, see *Backup*, p.38.

1. From the Home screen, tap  **Add** →  **A contact**. You may have to select the account where to save contacts to.
2. Enter contact information and continue to fill in the information you know. Tap **More fields** to add additional information for the contact.
3. Your new contact is created when you tap **Save**.

**Tip:** To hide the keyboard tap  and to activate the keyboard simply tap a text field once again.

## Manage your contacts



1. From the Home screen, tap  **View** →  **My contacts**.

2. Find and tap the wanted contact to open it.
3. Tap  to add as favourite contact.
4. Tap **Edit contact** if you want to change any details.
5. Tap  to add image.
6. Follow the on-screen instructions to complete contact information.
7. Tap **Save**, when you are done. Your contacts are automatically synced with your Google account (provided that you are logged onto your Google account). To manage synchronisation for your Google account, see *Backup*, p.38.

**Tip:** The favourite-contacts are easily found on the top of the contact list.

## Add a contact shortcut to the home screen

You can easily add a shortcut widget for a contact to your home screen.

1. From the Home screen, tap  **Set** →  **My homepage** → **My widgets**.
2. Find **Contacts** and select the type of shortcut you want. Touch & hold to place the shortcut where you want it.
3. Find and tap the wanted contact.


## Import and export contacts

For more help about importing and exporting contacts, see [support.google.com/contacts/](https://support.google.com/contacts/).

**Note!** For best performance, import your SIM contacts and save them to your Google account. By storing your contacts on your Google account, you minimise the risk of losing them in case of a SIM card failure or a lost phone.


## How to find the ICE contacts

In case of emergency (ICE) enables first responders to contact your next of kin or any of your stored contacts.

**Note!** The emergency information must firstly be filled in. See *ICE (In Case of Emergency)* , p.53.




## How to find the ICE contacts from locked screen

1. Swipe to unlock the screen.

2. Tap **Emergency** → tap **Emergency information** twice to see the stored ICE information.
3. Tap  to call an ICE contact.

**Note!** Only applies when screen lock method is set to **Pattern**, **PIN** or **Password**, and you must have added your ICE information. To activate the screen lock or change the type of screen lock, see *Screen lock*, p.11.

### How to find the ICE contacts in the menu

1. From the Home screen, tap  **View** →  **My phone information** →  **Phone status**.
2. Tap **Emergency information** to see the stored ICE information.


## Assistance options

### My assistance button

#### IMPORTANT!

You need an Internet connection to use this service. Contact your service provider for detailed data subscription costs before activating.

### Make an assistance call

The Assistance button on the back of the phone allows easy access to contact your predefined **Responders** (family and friends) if you should need help. The function relies on that the **Responder** of an assistance alert has the smartphone app, **Response by Doro** installed on their smartphone and the link with the Senior's Doro phone is setup. See *Response by Doro* , p.50


When the setup is done:

- Press and hold the assistance button on the back of the phone for 3 seconds, or press it three (3) times within 1 second. The assistance alert is sent after a delay of 5 seconds. In this time you can prevent a possible false alarm by pressing **Cancel**.
- An assistance alarm is now initiated and your **Group of Responders** will be alerted with your distress signal and your latest known location.



- The first person to confirm the alarm becomes responsible for it, and can call you to inquire the reason for your alarm, as well as take appropriate action.

### IMPORTANT!

To improve security even further, you can subscribe to the service Response Premium by Doro. See more at *Response Premium by Doro* , p.53.


## Response by Doro

### IMPORTANT!

You need an Internet connection to use this service. Contact your service provider for detailed data subscription costs before activating.

Before the assistance button can be used, the user of the Doro 8050 (called Senior) need at least one relative/helper (called Responder) that has created an account and connected with you.

The user of the Doro phone as well as the **Responders** (family and friends) needs to have an account for **Response by Doro** to use the service. A valid mobile phone number is needed to create a **Response by Doro** account

With  **Response by Doro** setup, relatives/helpers (**Responders**) can receive assistance alarm as well as check the status of the Doro phone and quickly assist with some basic phone settings, like sound and display settings, via the smartphone app **Response**.

There can be many helpers, but the first person that sets up an account and invites the **Senior** user will be the **Admin** for that **Senior**.

The **Group of Responders** can be just one **Responder** or several that can assist the **Senior**.

### For the Responder

#### Download and install the app Response by Doro

Before you setup an account you need to download and install the app Response by Doro.

For iPhones



<https://apps.apple.com/app/response-by-doro/id1437509312>

For Android phones



<https://play.google.com/store/apps/details?id=com.doro.apps.mydoro.relative>

### Create an account in the app Response by Doro

The first **Responder** that sets up an account and invites the **Senior** user will be the **Admin** for the **Group of Responders**.

1. Start the app and grant the required privileges.

**Note!** If needed, you should also grant Response by Doro access when your phone is set to "Do Not Disturb". Press back to return.

2. After a few short descriptions of the app, you need to agree with the terms and conditions for the service. Check the box and press **Next**.
3. Enter your mobile number and press **Next**.
4. Enter your **First name** and **Last name** and press **Next**.
5. You will receive a text message (SMS) shortly with an verification code. If you don't receive the message, make sure you have entered the correct number. Press **Resend text** to resend a the message.
6. Your account has now been verified and now you should complete the set-up by inviting the Senior that you wish to be able to assist. See *Add Senior*, p.52.

---

**Note!** To help the Doro phone user remotely from a computer a

**Responder** can also visit the web page [www.mydoro.com](http://www.mydoro.com).

The My Doro Manager helper application that is available through Play Store or App store is for older phone models and is **NOT** compatible with Doro 8050.

### Add Senior

You should now complete the set-up by inviting the **Senior** that you wish to be able to assist. The Senior will receive an invitation text message/SMS explaining the service Response by Doro and how to set it up and accept your invitation. Always inform the **Senior** user that you will start the service as it will require actions from the **Senior** user also.

1. Press **Invite**, or if you would like to add another **Senior** to assist, the press **Add Senior**.
2. Find the wanted contact, change the name if wanted, then press **Send**.
3. The Senior will receive an invitation text message/SMS explaining the service Response by Doro and how to accept your invitation. Press **DONE**.

### For the senior

#### Accept the invitation on the Doro 8050

1. You will receive an invitation via text message/SMS.
2. Start the app **Response** and agree with the terms and conditions for the service. Check the box and press **Next**.
3. Enter your mobile number and press **Next**.
4. You will receive a text message (SMS) shortly with a verification code. If you don't receive the message, make sure you have entered the correct number. Press **Resend text** to resend a the message.
5. Your account has now been verified and now you should complete the set-up by accepting the invitation.
6. Press **Open** next to the name of the person who invited you and then **Accept**.

**Senior** and **Responder** are now connected and the **Senior** can make an alarm with the assistance button on the back of the Doro phone to test the service.

The **Responder** can now also use the app **Response** to check the status of the Doro phone and quickly assist with some basic phone settings, like sound and display settings.

Both the **Senior** and the **Responder** can now also invite more persons to act as **Responders**.

## Response Premium by Doro

### IMPORTANT!

Note that this service is only available on some markets/countries.

Response Premium by Doro is a, easy-to-use service from Doro, created to give seniors and relatives extra security, every day. By pressing the assistance button on the Doro phone, the user can easily call for help. First the alarm contacts the relatives, and if no relative can respond, the alarm is automatically transferred to one of Doro's Alarm Receiving Centres, where Doro's well-trained and friendly operators will be able to assist 24/7.




The relatives (**Responders**) can use any iOS or Android smartphone.


Read more at [www.doro.com](http://www.doro.com).

## ICE (In Case of Emergency)

In the event of a trauma, it is critical to have this information as early as possible to increase the chances of survival. Add ICE contact to improve your own safety. First responders can access additional information such as medication and next of kin from your phone in case of an emergency. All fields are optional, but the more information provided the better.

**Note!** Your ICE contacts are fetched from your Contact book and you need to make sure that relevant information is stored on each ICE contact.

1. From the Home screen, tap  **Set** →  **An assistance option** →  **My ICE information**.
2. Tap **Add information** to enter your medical information. Follow the on-screen instructions to complete the ICE-card information.
3. Tap **Add contact** to add and ICE contact.




**Note!** To remove an ICE contact tap  next to the ICE contact.

## The remote help

Let somebody you trust manage your phone remotely, for example, this can be requested when you contact Doro support. Allow access so they can remotely administrate and transfer files, help you to perform maintenance tasks and help with problems should they occur.

The person performing the remote help must have Teamviewer installed. Teamviewer can be downloaded and installed for many different operating systems at <http://www.teamviewer.com/download/>.

### To connect a remote support session

1. From the Home screen, tap  **Set** →  **An assistance option** →  **The remote help**.
2. Share **Your ID** with your personal tech support to allow remote control. Tap **Send my ID...** to select how to share your ID.
3. Follow the on-screen instructions.
4. To quit TeamViewer, open the Notification panel, swipe the status bar down. Click QuickSupport and tap **X** in the upper right corner.
5. Confirm with **Close**.

**Note!** All TeamViewer connections are highly encrypted and are thus protected from being accessed by third parties. For detailed technical information regarding connections, security and data privacy in TeamViewer, see the security statement at <http://www.teamviewer.com/en/products/security.aspx>.


## Google search


### IMPORTANT!


You need an Internet connection to use this service. It is recommended to use Wi-Fi connections when available to reduce costs for data traffic. Contact your service provider for detailed subscription costs before activating.

**Note!** The available options may vary depending on your device settings.

## To use the web browser

1. From the Home screen, tap the Google™ search field .
 

**Note!** The first time you are asked if you want to Sign in with your Google account.
2. Tap next to  to search the Internet, to search you type words, or you can paste text, copied by you.
3. When you start a search on Google, you can find information faster by looking at search predictions. Search predictions are possible search terms you can use that are related to the terms you're typing and what other people are searching for.
4. Tap to select the best matching search results.
 

To go back, tap .


## Applications

Applications can be a program or game that you can use on your Doro 8050. Depending on market and service provider, the pre-installed applications can vary. Some applications need Internet access. Contact your service provider for detailed subscription costs before activating. Some applications need to be purchased. The cost is shown in the application description as well as if it is free. Using downloaded and installed applications does not cost anything, except if an Internet connection is needed.

Use *Google™ Play Store* to download and install all the applications you need.







## Messages

### Write messages

You can send different types of messages from your phone. Here we will explain how to send a text message, but you can also send other message types from the  **Send** menu.




**Tip:** Text messages (SMS) are delivered immediately to a device that most of us have with us at all times, a text message also represents a more personal and intimate connection. Most modern smartphones can receive emails (that may be preferable for more formal communications or inquiries) but texting remains simpler and is the only option for those using a more basic cell phone.

You can find more help regarding Messages on [support.google.com/messages/](https://support.google.com/messages/).

1. From the Home screen, tap  **Send** →  **A message**.
2. Tap  **To a number**/ **To a contact**.
3. Enter the phone number, you are offered suggestions as you type or search among your stored contacts.
4. Tap  or tap a suggested contact.
5. Compose your message.
6. When done, tap  to send.

**Note!** If you choose to add multiple recipients, you may be charged for each recipient. You may also incur additional charges for sending messages when you are roaming. It is recommended to use Wi-Fi connections when available to reduce costs for data traffic.

## Messages settings

1. From the Home screen, tap  **View** →  **My messages**.
2. Tap  → **Settings**.

**Note!** Message settings are normally already set and should not need to be altered by you, unless, of course you want to make changes. Some features are network services and you may need to subscribe to them first. For more information contact your service provider.

## Email








### IMPORTANT!

You need an Internet connection to use this service. It is recommended to use Wi-Fi connections when available to reduce costs for data traffic. Contact your service provider for detailed subscription costs before activating.




**Tip:** Gmail is pre-installed and available under Google that you reach from the Home screen. For more help see [support.google.com/mail/](https://support.google.com/mail/). You can of course install other email client apps if you wish.


## Write emails

Here we will explain how to send an email to a contact that is available in your contact book.




1. From the Home screen, tap  **Send** →  **An email**.
2. Tap  **To contact**.  
Alternatively tap  **To email address**.
3. Tap to select one or several contacts.
4. Compose your text.
5. Enter a subject.
6. Tap  to attach files to the email.
7. Tap  for more options.
8. When done, tap  to send.

## Read emails

1. From the Home screen, tap  **View** →  **My emails**.
2. Tap to read an mail.
3. Tap  for more options.

**Note!** Please note that there are two icons  for more option.

## Email settings

1. From the Home screen, tap  **View** →  **My emails**.
2. Tap  → **Settings**.



## Camera

**Tip:** To get sharp photos, wipe the lens clean with a dry cloth.

**Note!** Do not take photos or record videos of other people without their permission. Do not take a photo or record a video where prohibited or where you may be violating others' integrity.





## How to open the Camera



1. From the Home screen, tap  **Camera**.
2. Tap camera button  in the app to take a picture.

## How to take a selfie



Selfie means to take a picture of yourself. You can use the front camera to take self-portraits.

1. On the camera preview screen, tap  to switch to the front camera for self-portraits.
2. Face the front camera. Move the camera around until you find a pleasing pose.
3. When you see your face in the display, tap  to take a picture of yourself.

## How to record a video

1. On the camera preview screen tap **Video**.
2. Tap  to record a video. Tap  to stop recording.
3. Tap **Camera** to return to camera mode.




## Camera settings

1. Tap  to access camera settings.
2. Tap to reach and select the different settings. Tap  to exit camera settings.

**Tip:** You can also access your gallery from camera mode, on the camera preview screen, select the thumbnail in the lower left corner.

## Handle pictures in the Gallery

### View/handle pictures or videos

1. From the Home screen, tap  **View** →  **My pictures and videos**.
2. Tap  for more options.
3. Select the photo/video to view/play.
4. Swipe to the left or right for the next or previous image/video. Swipe up for details. Tap to get more options.




**Tip:** For more help see [support.google.com/photos/](https://support.google.com/photos/)

## Internet (Web browser)

### IMPORTANT!

You need an Internet connection to use this service. It is recommended to use Wi-Fi connections when available to reduce costs for data traffic. Contact your service provider for detailed subscription costs.

### To use the web browser

1. From the Home screen, tap  **Search** →  **Something on the Internet**.
2. Enter the word or phrase that you would search and tap .

**Note!** The first time you are asked if you want to Sign in with your Google account.




You can also enter the search word or phrase directly in the Google bar on the homepage.

**Tip:** For more help see [support.google.com/websearch/](https://support.google.com/websearch/)

### Dock mode

When you phone is placed in the charging cradle it will automatically enter what is called dock mode. Dock mode will activate the screen saver that turns your Doro 8050 into a side-table clock unless set otherwise. The screen will dim and turn off after a while. Press the home or power button to wake up the screen.

### Screen saver settings


1. From the Home screen, tap  **Set** →  **Advanced settings** → **Display** → **Advanced** → **Screen saver**.
2. Tap **Current screen saver** to change screen saver.
3. Tap  to adjust the settings for the screen saver.
4. Tap **When to start** to set when the screen saver should start.

Tap **Start now** to start the screen saver for testing.

### Music

You can listen to music and audio files stored on your phone as well as music from internet.

## Play music



1. From the Home screen tap **Google** folder and tap **Play Music**. The first time you start this app you will be asked if you want to subscribe to Google's music.
2. Tap  → **Music library** to see your available music.
3. Select from different categories like playlists, artists, albums.

**Tip:** While you're listening to music you can start and pause the music from the quick settings in the Notification panel. To open the Notification panel, swipe the status bar down. You can also use other features and apps while listening to music.







For more help see [support.google.com/googleplaymusic/](https://support.google.com/googleplaymusic/).

## Calendar

### Add an event

1. Tap  **Add** →  **An event**.
2. Follow the on-screen instructions to complete the event.
3. Tap **Save** to confirm.

### To edit or delete events

1. Tap  **View** →  **My calendar**.
2. Scroll or tap  →  **Search** to find the wanted entry.
  - Tap  to edit.
  - Tap  → **Delete** to delete the event.



For more help see [support.google.com/calendar/](https://support.google.com/calendar/).

## Alarm

### Set alarms




The phone must be powered on in order for the alarm to function properly.

**Tip:** Alarms will sound even in silent mode.

1. From the Home screen, tap  **Add** →  **An alarm** and follow the on-screen instructions.



**Tip:** To save battery and prevent incoming calls or messages, you can turn on **Aeroplane mode** but still keep the alarm function, see *Aeroplane mode*, p.35.

### To edit or delete alarms

1. From the Home screen, tap  **Set** →  **My alarms**.
2. To turn on and off switch .
3. Tap an alarm to edit it.

### Stop or snooze an alarm

Slide  to:






-  **Snooze**, to snooze the alarm for 10 minutes.
-  **Stop**, to stop the alarm.

## Timer

Use the timer to count down from a specified time interval.

**Tip:** The timer will sound even in silent mode.




### Add a timer

1. From the Home screen, tap  **Add** →  **A timer**.
2. Set the duration of the timer and tap  to start the countdown.
3. Tap  to pause and  to stop.




## My notes

This feature uses Google Keep™.

### Add a note


1. Tap  **Add** →  **A note**.
2. Enter required information.
3. For more options, tap .

### View/edit/delete a note

1. Tap  **View** →  **My notes**.
2. Tap the wanted note and edit if needed.
3. For more options, tap .

For more help see [support.google.com/keep/](https://support.google.com/keep/).


## Torch

Swipe down the notification panel and tap  **Torch** to turn on the light. Tap again to turn off.

**Note!** The battery will drain very quickly. Remember to switch off after use.

## Calculator

Perform simple calculations.

1. From the Home screen swipe up or tap the arrow  at the bottom of the Home screen and tap the app **Calculator** to open it
2. Enter the first number, select an operation (+, -, x, ÷) and enter next number. Repeat if needed.
3. Select = to calculate the result.

Tap **del** to delete the latest entry.

Tap **clr** to clear the result.

## Google apps

### IMPORTANT!

You need an Internet connection to use this service. It is recommended to use Wi-Fi connections when available to reduce costs for data traffic. Contact your service provider for detailed subscription costs before activating.

All pre-installed Google™ applications can be found in the **Google** folder. Depending on the market, the pre-installed applications can vary. To view more app information, access each app's help menu.

**Note!** Some apps may not be available or may be labelled differently depending on the region or service provider.

- From the Home screen select **Google** to open the Google™ applications.
  - **Google** quickly search for items on the Internet or on your phone.
  - **Chrome** search for information and browse webpages.
  - **Gmail** send or receive emails via the Google Mail service.
  - **Maps** find your location on the map, search for locations, and view location information for various places.

- **YouTube** watch or create videos and share them with others
- **Drive** store your content on the cloud, access it from anywhere, and share it with others.
- **Play Music** discover, listen to, and share music on your phone. You can upload music collections stored on your device to the cloud and access them later.
- **Play Movies & TV** download videos to watch from Play Store, see *Google™ Play Store*, p.43.
- **Duo** chat individually or in groups with your friends.
- **Photos** search for, manage, and edit all your photos and videos from various sources in one place.


## The cloud

The cloud is not a physical thing. The cloud is a network of servers, and each server has a different function. Some servers use computing power to run applications or "deliver a service." For example, when you take a picture on your smartphone, it is stored on your phone's internal memory drive. However, when you upload the photos to Instagram, you are uploading it to the cloud.

So remember: The Cloud is a network of servers. Some servers provide an online service, and others allow you to store and access data, like Instagram or Dropbox. Chances are, you encounter the cloud daily. From Google Drive to Evernote, any time you store information without using up your phone's internal data, you're storing information in the cloud.





## Location based services

LBS stands for Location-Based Service and is a software application for mobile devices that requires knowledge about where the device is located. The service can be query-based and it can provide you with useful information such as "Where is the nearest restaurant?". The service can also be push-based and send you coupons or let you view commute traffic. By law, location-based services must be permission-based. That means that you must opt in (actively say yes) to the service in order to use it.

**Tip:**  is shown in the status bar when your phones location is being used by any app.

**Note!** Turning off location for your device also turns it off for Google apps and other non-Google apps. This means that apps can't use your phone's location, and many useful features will be turned off.

### How to turn off GPS location services























1. From the Home screen, open the notification panel, tap  **Set** →  **My other connections** →  **The geolocation options**.
2. Switch  to disable location services.



#### CAUTION

If you turn off location-based services apps such as map, navigation, and weather applications cannot access your location information.

### Status icons

	Mobile network		Wi-Fi network
	Roaming (in other network)		Bluetooth on
	Vibrate mode		Data transmission: data in ▼, data out ▲.
	Silent mode		Error occurred or caution required
	Flight mode		Alarm active
	Google Play Store software updates available		System update available
	Unread email (in the gmail app)		New text message or multi- media message
	GPS activated		SIM card not inserted
	Headset connected (without microphone)		Battery level
	Missed call		Headset connected (with mi- crophone )
	Call forwarding on		Call ongoing

## Safety instructions



### CAUTION

The unit and the accessories can contain small parts. Keep all of the equipment out of the reach of small children.

The mains adapter is the disconnect device between the product and mains power. The mains socket outlet must be close to the equipment and easily accessible.

## Network services and costs

Your device is approved for use on the 4G LTE: 1 (2100), 3 (1800), 7 (2600), 8 (900 MHz), 20 (800), 28 (700) MHz / WCDMA: 1 (2100), 2 (1900), 5 (850), 8 (900) MHz / GSM: 850, 900, 1800, 1900 MHz networks. To use the device, you need a subscription with a service provider.

Using network services may result in traffic costs. Some product features require support from the network, and you may need to subscribe to them.

## Operating environment

Follow the rules and laws that apply wherever you are, and always turn off the unit whenever its use is prohibited or can cause interference or hazards. Only use the unit in its normal user position.

Parts of the unit are magnetic. The unit can attract metal objects. Do not keep credit cards or other magnetic media near the unit. There is a risk that information stored on them can be erased.

## Wi-Fi (WLAN)

This equipment may be operated in all European countries.

The 5150 - 5350 MHz band is restricted to indoor use only.

AT	BE	BG	CH	CY	CZ	DE	DK	EE	ES	FI	FR
GR	HR	HU	IE	IS	IT	LI	LT	LU	LV	ME	MK
MT	NL	NO	PL	PT	RO	RS	SE	SI	SK	TR	UK

## Medical units

The use of equipment that transmits radio signals, for example, mobile phones, can interfere with insufficiently protected medical equipment. Consult a doctor or the manufacturer of the equipment to determine if it has adequate protection against external radio signals, or if you have any questions. If notices have been put up at health care facilities instructing you to turn off the unit while you are there, you should comply. Hospitals and other health care facilities sometimes use equipment that can be sensitive to external radio signals.





## Implanted medical devices

To avoid potential interference, manufacturers of implanted medical devices recommend a minimum separation of 15 cm between a wireless device and the medical device. Persons who have such devices should:

- Always keep the wireless device more than 15 cm from the medical device.
- Should not carry the phone in a breast pocket.
- Hold the wireless device to the ear opposite the medical device.

If you have any reason to suspect that interference is taking place, turn the phone off immediately. If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

## Areas with explosion risk

Always turn off the unit when you are in an area where there is a risk of explosion. Follow all signs and instructions. There is a risk of explosion in places that include areas where you are normally requested to turn off your car engine. In these areas, sparks can cause explosion or fire which can lead to personal injury or even death.

Turn off the unit at filling stations, and any other place that has fuel pumps and auto repair facilities.

Follow the restrictions that apply to the use of radio equipment near places where fuel is stored and sold, chemical factories and places where blasting is in progress.

Areas with risk for explosion are often – but not always – clearly marked. This also applies to below decks on ships; the transport or storage of chemicals; vehicles that use liquid fuel (such as propane or butane); areas where the air contains chemicals or particles, such as grain, dust or metal powder.

## Li-Polymer battery

This product contains a Li-Polymer battery. There is a risk of fire and burns if the battery pack is handled improperly.



### WARNING

Danger of explosion if battery is incorrectly replaced. To reduce risk of fire or burns, do not disassemble, crush, puncture, short external contacts, expose to temperature above 60° C (140° F), or dispose of in fire or water. Recycle or dispose of used batteries according to the local regulations or reference guide supplied with your product.

## Removing/replacing the battery

- To remove/replace the battery, contact an authorised service centre. Please find latest information at [www.doro.com](http://www.doro.com).
- For your safety, you must not attempt to remove the battery. If the battery is not properly removed, it may lead to damage to the battery and device, cause personal injury, and/or result in the device being unsafe.
- Doro does not accept liability for any damage or loss if these warnings and instructions are not followed.

## Protect your hearing

This device has been tested to comply with the Sound Pressure Level requirement laid down in the applicable EN 50332-1 and/or EN 50332-2 standards.



### WARNING

Excessive exposure to loud sounds can cause hearing damage. Exposure to loud sounds while driving may distract your attention and cause an accident. Listen to a headset at a moderate level, and do not hold the device near your ear when the loudspeaker is in use.

## Emergency calls

### IMPORTANT!

Mobile phones use radio signals, the mobile phone network, the terrestrial network and user-programmed functions. This means that connection cannot be guaranteed in all circumstances. Therefore, never rely only on a mobile phone for very important calls such as medical emergencies.

## GPS/Location based functions

Some products provide GPS/Location based functions. Location determining functionality is provided "As is". No representation or warranty are made as to the accuracy of such location information. Use of location-based information by the device may not be uninterrupted or error free and may additionally be dependent on network service availability. Please note that functionality may be reduced or prevented in certain environments such as building interiors or areas adjacent to buildings.



### CAUTION

Do not use GPS functionality in a manner which causes distraction from driving.

## Vehicles

Radio signals can affect electronic systems in motor vehicles (for example, electronic fuel injection, ABS brakes, automatic cruise control, air bag systems) that have been incorrectly installed or are inadequately protected. Contact the manufacturer or its representative for more information about your vehicle or any additional equipment.

Do not keep or transport flammable liquids, gases or explosives together with the unit or its accessories. For vehicles equipped with air bags: Remember that air bags fill with air with considerable force.

Do not place objects, including fixed or portable radio equipment in the area above the airbag or the area where it might expand. Serious injuries may be caused if the mobile phone equipment is incorrectly installed and the airbag fills with air.

It is prohibited to use the unit in flight. Turn off the unit before you board a plane. Using wireless telecom units inside a plane can pose risks to air safety and interfere with telecommunications. It may also be illegal.

## Protect your personal data

Protect your personal data and prevent leakage or misuse of sensitive information

- While using your device, be sure to back up important data.
- When disposing of your device, back up all data and then reset your device to prevent misuse of your personal information.
- Carefully read the permissions screen when downloading applications. Be particularly cautious with applications that have access to many functions or to a significant amount of your personal information.
- Check your accounts regularly for unapproved or suspicious use. If you find any sign of misuse of your personal information, contact your service provider to delete or change your account information.
- In the event your device is lost or stolen, change the passwords on your accounts to protect your personal information.
- Avoid using applications from unknown sources and lock your device with a pattern, password, or PIN.

## Malware and viruses

To protect your device from malware and viruses, follow these usage tips. Failure to do so may result in damages or loss of data that may not be covered by the warranty service.

- Do not download unknown applications.
- Do not visit untrusted websites.
- Delete suspicious messages or email from unknown senders.
- Set a password and change it regularly.
- Deactivate wireless features, such as Bluetooth, when not in use.
- If the device behaves abnormally, run an antivirus program to check for infection.
- Run an antivirus program on your device before you launch newly-downloaded applications and files.
- Do not edit registry settings or modify the device's operating system.

## Care and maintenance

Your unit is a technically advanced product and should be treated with the greatest care. Negligence may void the warranty.

- Protect the unit from moisture. Rain, snow, humidity, and all types of liquids can contain substances that corrode the electronic circuits. If the unit gets wet, you should immediately power off the phone, remove the battery and allow the unit to dry completely before you replace it.
- Do not use or keep the unit in dusty, dirty environments. The unit's moving parts and electronic components can be damaged.

- Do not keep the unit in warm places. High temperatures can reduce the lifespan for electronic equipment, damage batteries and distort or melt certain plastics.
- Do not keep the unit in cold places. When the unit warms up to normal temperature, condensation can form on the inside and can damage the electronic circuits.
- Do not try to open the unit in any other way than that which is indicated here.
- Do not drop or shake the unit. If it is treated roughly the circuits and precision mechanics can be broken.
- Do not use strong chemicals to clean the unit.
- Do not disassemble, open, crush, bend, deform, puncture or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per IEEE-Std-1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Improper battery use may result in a fire, explosion or other hazard.

For devices that utilize a USB port as a charging source, the device's user manual shall include a statement that the device shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

The advice applies to the unit, battery, power adapter and other accessories. If the phone is not working as it should, please contact the place of purchase for service. Don't forget the receipt or a copy of the invoice.

## Warranty

This product is guaranteed for a period of 24 months and for original accessories for a period of 12 months (such as the battery, charger, charging cradle or handsfree kit) which may be delivered with your device, from the date of purchase. In the unlikely event of a fault occurring during this period, please contact the place of purchase. Proof of purchase is required for any service or support needed during the guarantee period.

This guarantee will not apply to a fault caused by an accident or a similar incident or damage, liquid ingress, negligence, abnormal usage, non-maintenance or any other circumstances on the user's part. Furthermore, this guarantee will not apply to any fault caused by a thunderstorm or any other voltage fluctuations. As a matter of precaution, we recommend disconnecting the charger during a thunderstorm.

Please note that this is a voluntary manufacturer's warranty and provides rights in addition to, and does not affect statutory rights of end-users.

This guarantee does not apply if batteries other than DORO original batteries are used.

## Specifications

### Network bands (MHz):

2G GSM:	850, 900, 1800, 1900
3G UMTS:	1 (2100), 2 (1900), 5 (850), 8 (900)
4G LTE FDD:	1 (2100), 3 (1800), 7 (2600), 8 (900) 20 (800), 28 (700)
Wi-Fi (MHz):	WLAN IEEE 802.11 a/b/g/n, (2412 - 2472) + (5150 - 5875)
Bluetooth (MHz):	4.2, (2402 - 2480)
GPS receiver:	GPS/BEUDOU/Galileo/GLONASS
Operating system:	Android 9 Pie
SIM card size:	nano-SIM (4FF)
Dimensions:	153 x 71 x 9 mm
Weight:	165 g (including battery)
Battery:	3.85 V / 3000 mAh Li-Polymer battery
Image format:	BMP, GIF, JPG, PNG
Video format:	AVI, MP4, 3GP, 3GP2
Audio format:	WAV, AMR, MIDI, MP3, AAC
Main camera resolution:	13
Front camera resolution:	5
Camera digital zoom:	4x
Display Size:	5.45"
Display resolution:	720 x 1440
RAM:	2 GB
Internal memory:	16 GB
External memory:	microSD, microSDHC, microSDXC max 128 GB

---

Sensors:	Accelerometer, Light sensor, Proximity sensor, Compass
USB Interface:	USB-C
Headset connector:	3.5mm Stereo
Operating ambient temperature:	Min: 0° C (32° F) Max: 40° C (104° F)
Charging ambient temperature:	Min: 0° C (32° F) Max: 40° C (104° F)
Storage temperature:	Min: -20° C (-4° F) Max: 60° C (140° F)

## Copyright and other notices

Bluetooth® is a registered trademark of Bluetooth SIG, Inc.

vCard is a trademark of the Internet Mail Consortium.

eZiType™ is a trademark of Zi Corporation.

Wi-Fi is a trademark or a registered trademark of the Wi-Fi Alliance.

microSD is a trademark of SD Card Association.

Java, J2ME and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Doro reserves the right to revise this document or withdraw it at any time without prior notice.

Google, Google Maps™, Gmail, Google Calendar, Google Checkout, Hangouts, YouTube, the YouTube logo, Picasa and Android are trademarks or registered trademarks of Google LLC.

This product is licensed under the MPEG-4 visual and AVC patent portfolio licenses for the personal and noncommercial use of a consumer for (i) encoding video in compliance with the MPEG-4 visual standard ("MPEG-4 video") or the AVC standard ("AVC video") and/or (ii) decoding MPEG-4 or AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed by MPEG LA to provide MPEG-4 and/or AVC video. No license is granted or shall be implied for any other use. Additional information including that relating to promotional, internal and commercial uses and licensing may be obtained from MPEG LA, L.L.C. See [www.mpegla.com](http://www.mpegla.com). MPEG Layer-3 audio decoding technology licensed from Fraunhofer IIS and Thomson.

Other product and company names mentioned herein may be the trademarks of their respective owners.

---

Any rights not expressly granted herein are reserved. All other trademarks are property of their respective owners.

To the maximum extent permitted by applicable law, under no circumstances shall Doro or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

Doro does not provide a warranty for or take any responsibility for the functionality, content, or end-user support of third-party apps provided with your device. By using an app, you acknowledge that the app is provided as is. Doro does not make any representations, provide a warranty, or take any responsibility for the functionality, content, or end-user support of third-party apps provided with your device.

## Content copyright

The unauthorised copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright, or materials which you are authorised or legally permitted to copy. If you are uncertain about your right to copy any material, please contact your legal advisor.

## Open source licenses

You are entitled to receive a copy of the source code of software licensed under an open source license that gives you the right to receive the source code for that software (for example GPL or LGPL) to you on an appropriate media, against an administrative fee covering Doro AB's cost for handling the distribution and costs for media. Please direct such request to Doro AB, Open Source Software Operations, Jorgen Kocksgatan 1B, SE 211 20 Malmö, Sweden. To be valid, such a request must be made within three (3) years from the date of the distribution of this product by Doro AB, or in the case of code licensed under the GPL v3 for as long as Doro AB offers spare parts or customer support for this product model.

## Hearing aid compatibility

**Note!** For hearing aid compatibility, turn off Bluetooth connectivity.

This phone is hearing aid compatible. Hearing aid compatibility is not a guarantee that a specific hearing aid will work with a specific phone. Mobile phones contain radio transmitters that may interfere with hearing aid performance. This phone has been tested for use with hearing aids, for some of the wireless technologies that it uses, but there may be some newer wireless technologies that have not been tested yet for use with hearing aids. To ensure that a specific hearing aid works well with this phone, test them together before making a purchase.

The standard for hearing aid compatibility contains two types of ratings:

- **M:** To use your hearing aid in this mode, make sure that your hearing aid is set to "M-mode" or acoustic coupling mode, and position the phone's receiver near the hearing aid's built-in microphone. For the best results, try using the phone in different positions relative to your hearing aid—for example, placing the receiver slightly

above the ear may result in better performance for hearing aids with microphones positioned behind the ear.

- **T:** To use your hearing aid in this mode, make sure that your hearing aid is set to "T-mode" or telecoil coupling mode (not all hearing aids have this mode). For the best results, try using the phone in different positions relative to your hearing aid—for example, placing the receiver slightly below or in front of the ear may result in better performance.

Your device meets the M3/T4 level rating.

## Specific Absorption Rate (SAR)

This device meets applicable international safety requirements for exposure to radio waves. Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines from the independent scientific organization ICNIRP (International Commission of Non-Ionizing Radiation Protection).

The World Health Organization (WHO) has stated that current scientific information does not indicate the need for any special precautions when using mobile devices. If you are interested in reducing your exposure, they recommend you reduce your usage or use a hands-free accessory to keep the device away from your head and body.

For information about SAR (Specific Absorption Rate) values for your device, please read the documentation provided together with your device.

## Correct disposal of this product



(Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or manual indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal. This product is RoHS compliant.

## Correct disposal of batteries in this product



(Applicable in countries with separate collection systems)

The marking on the battery, manual or packaging indicates that the battery in this product should not be disposed of with other household waste. Where marked, the chemical



symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

## **Declaration of Conformity**

Hereby, Doro declares that the radio equipment type DSB-0230 (Doro 8050) is in compliance with Directives: 2014/53/EU and 2011/65/EU including delegated Directive (EU) 2015/863 amending Annex II. The full text of the EU declaration of conformity is available at the following internet address: [www.doro.com/dofc](http://www.doro.com/dofc).

## **Ecodesign declaration, energy efficiency for external power supply**

Hereby, Doro declares the external power supply for this device is in compliance with Commission Regulation (EU) 2019/1782 regarding ecodesign requirements for external power supplies pursuant to Directive 2009/125/EC.

The full information regarding the ecodesign requirements is available at the following internet address: [www.doro.com/ecodesign](http://www.doro.com/ecodesign)

DSB-0230 (Doro 8050) (1031)

For Assistance:

Web: [www.doroaustralia.com.au](http://www.doroaustralia.com.au)

Email: [sales@doroaustralia.com.au](mailto:sales@doroaustralia.com.au)

Phone 61 2 9599 9555

English

Version 2.0

©2019 Doro AB. All rights reserved.



REV 19702 – STR 20190830